

INSERT WIRES IN PLASTIC PLUG  
PLUG IS CODED FOR THE COLOR  
OF THE WIRES

1



SEAT PLASTIC PLUG AGAINST  
AGAINST CONDUIT

2



3

PUSH PLUG INTO SOCKET ON UNDERSIDE  
OF HEADLIGHT (ONLY FITS ONE WAY!)



HOLDING PLUG INTO HEADLIGHT, TURN  
FERRULE CLOCKWISE TO LOCK ON

4

